


Deslimer[®]

Condensate Drain Pump

Deslimer[®] easily clears stubborn blockages with a few quick pumps. Its dual-action aluminum and stainless steel design generates powerful suction and pressure to break up and clear blockages with no chemicals, no compressed air, no hassle.



How to Use the Deslimer:

1. **Locate the blocked Condensate Drain Line** and connect Deslimer[®] to the discharge end of the drain using the coupling provided.
2. **Start Pumping** - Begin with a full upward stroke on the handle then continue pumping the handle 10 to 20 times using a steady motion. Deslimer's dual-action pump creates suction and pressure on each stroke to break up blockage and flush debris.
3. **Check Drainage** by disconnecting Deslimer[®] from the condensate drain line. Water, slime and debris should flow freely from the drain line discharge.
4. **If blockage remains**, reconnect and continue pumping until blockage is cleaned and condensate water flows normally.

Maintenance:

- Rinse the Deslimer after each use by pumping clean water.
- Store in a dry place.
- Replace sealing washers annually or as needed to ensure pump performance.

Part #: DS-1

UPC: 811095021005

Consumable Items: BUNA-N Sealing Washers - Use part# DS-SEAL (qty=2)

For assistance visit www.ngf.com, email requests@ngf.com or call +1 561-848-1826